

# WALL & WALL PREP SUGGESTIONS

V 1.25

## THE WALLS

- MAKE SURE YOUR SMOOTH WALL HAS BEEN PRIMED AND PAINTED. IF IT HASN'T, WE RECOMMEND USING THE ZINSSER DRYWALL PRIMER FLAT. ONCE DRY, YOU CAN APPLY SAME DAY.
- IF THE WALL WAS RECENTLY PAINTED, WAIT 30-45 DAYS TO MAKE SURE THE PAINT HAS COMPLETELY OUTGASSED AND FIRST TEST FOR BUBBLES.

**\*DO NOT USE THE SHIELDZ (ZINSSER) WALL PRIMERS\***



## PROPER WALL PREP IS ALWAYS A MUST

- THE BEST METHOD OF CLEANING IS TO USE 70% ISOPROPYL ALCOHOL & 30% WATER MIXED. CLEAN 2X WITH A LINT-FREE MICROFIBER TOWEL. WIPE IN ONLY ONE DIRECTION (NO CIRCULAR MOTIONS). THIS METHOD IS A MUST WITH LOW/NO VOC PAINTS.



## ROUGH SURFACE OR LIGHTLY TEXTURED?

- IF YOU FEEL THAT YOUR WALL HAS SLIGHT IMPERFECTIONS OR TEXTURED, USE A 3M GOLD SANDING SPONGE AND LIGHTLY SAND THE WALL. DO NOT PRESS HARD, AS IT COULD DAMAGE THE PAINT. AFTER SANDING USE THE 70/30 WALL PREP METHOD ABOVE.



## HAVE NO TIME TO WAIT?

- IF YOU ARE PRESSED FOR TIME AND STILL CONCERNED ABOUT THE WALLS OR TEXTURED SURFACES NOT BEING STABLE.

WE RECOMMEND USING THE ROMAN PRO 880 ADHESIVE CLEAR PRIMER. YOU WILL APPLY THIS AT THE SAME TIME AS INSTALLATION, WET. DO NOT LET THIS DRY. APPLY PRIMER ON ONE OR TWO PANELS AT A TIME (BE CAREFUL NOT TO GET THE GLUE ON THE PRINTED SIDE).



DISCLAIMER: THE INFORMATION CONTAINED IS FOR SUGGESTION PURPOSES ONLY. PHOTO TEX GROUP, INC. OR ANY OF ITS AFFILIATES CANNOT BE HELD RESPONSIBLE FOR WALL DAMAGE.